HOME
DECORATORS
COLLECTION

STEED CONSOLE WHITE WASH DISTRESS(6299300940)

Assembly Instructions

Hardware Included



Wooden top and shelf - 2 Nos.



Metal legs - 8 Nos.



Lower metal bar - 4 Nos.



Upper metal bar - 2 Nos.

Allen Key:1 Pcs



8 Pcs(38 mm) Nut and Bolt



4 Pcs(56 mm) Nut and Bolt



Allen Bolts 12 Pcs

Note: 1- Do not throw away packaging materials until assembly is complete.
2- Assemble this item on a soft surface, such as cardboard or carpet, to protect finish.
3- Proper assembly of this item requires 2 adults.

Step-1 Align the holes of metal legs with center part. Attach the metal legs with center part ensuring that position marked as 'A' on leg 'A' matches with position 'A' on lower metal bar and 'B' with 'B' and tighten with the help of spanner (Not Included) as shown in the image. (Similarly match 'E' to 'E', 'F' to 'F', 'G' to 'G' and 'H' to 'H' and so on.)



Step-2 Align the hole of upper metal bar with the 2 assembled metal legs as shown in image.



Step-3 Screw both the part carefully as shown in image. Make the 2 set of legs with the help of above mentioned instructions.



Step-4 Lay the top up side down on smooth surface as shown. Attach both the legs on the top with the help of allen bolts using allen key, ensuring that position ‘I’ on wooden top matches with position ‘I’ on metal leg.



Step-5 Attach wooden shelf as shown in the image.



Step-6 Tighten wooden shelf with the help of allen bolts using allen key, ensuring that position 'J' 'J' marked on wooden shelf matches with position "J" on metal leg.



Step-7 Turn the table upright. Assembly is complete.



Care Instructions:

- Dust often using a clean, soft, dry and lint-free cloth.
- Blot spills immediately and wipe with a clean, damp, cloth.
- We do not recommend the use of chemical cleansers, abrasives or furniture polish on our lacquered finish.
- Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary.